

COPERTURA PER GRUPPO INAIL/ SEPARATORE IDRAULICO PER CALDAIA STAND ALONE

Questa istruzione è parte integrante del libretto dell'apparecchio sul quale viene installato l'accessorio.
A tale libretto si rimanda per le AVVERTENZE GENERALI e per le REGOLE FONDAMENTALI DI SICUREZZA.

- ⚠ Prima di effettuare qualsiasi operazione togliere l'alimentazione elettrica all'apparecchio.
- ⚠ Questo accessorio deve essere installato solo da personale professionalmente qualificato.

Il kit è composto da:	Q.tà
1 Mantello frontale	1
2 Parete destra	1
3 Parete sinistra	1
4 Protezione inferiore chiusura	1
5 Molletta per mantello	4
6 Perno per molletta per mantello	4
7 Vite 3,9x9,5	8
8 Vite autofilettante 6,3x16	6
9 Foglio istruzioni	1

COVER FOR INAIL SAFETY/ HYDRAULIC SEPARATOR FOR STAND ALONE BOILER

These instructions are an integral part of the installer manual on which the accessory is installed.
See the manual for the GENERAL WARNINGS, GENERAL SAFETY DEVICES.

- ⚠ Before carrying out any operation, first disconnect the electric power supply to the boiler.
- ⚠ The accessory must be installed by professional qualified personnel.

The kit is composed by:	Q.ty
1 Front cover	1
2 Right wall	1
3 Left wall	1
4 Lower closure protection	1
5 Cloak clip	4
6 Pin for cloak clip	4
7 Screw 3,9x9,5	8
8 Self-tapping screw 6,3x16	6
9 Instruction sheet	1

