

IT

## KIT VALVOLA DI SICUREZZA INAIL FINO A 400 KW (4,5 BAR)

Questa istruzione è parte integrante del libretto dell'apparecchio sul quale viene installato l'accessorio.

A tale libretto si rimanda per le AVVERTENZE GENERALI e per le REGOLE FONDAMENTALI DI SICUREZZA.

- ⚠ Prima di effettuare qualsiasi operazione togliere l'alimentazione elettrica all'apparecchio.
- ⚠ Questo accessorio deve essere installato solo da personale professionalmente qualificato.

Il kit è composto da:

- 1 Valvola di sicurezza INAIL 4,5 bar
- 2 Nipplo
- 3 Foglio istruzioni

Q.tà

- 1
- 1
- 1

EN

## INAIL SAFETY VALVE KIT UP TO 400 KW (4.5 BAR)

These instructions are an integral part of the installer manual on which the accessory is installed.

See the manual for the GENERAL WARNINGS, GENERAL SAFETY DEVICES.

- ⚠ Before carrying out any operation, first disconnect the electric power supply to the boiler.
- ⚠ The accessory must be installed by professional qualified personnel.

The kit is composed by:

- 1 INAIL safety valve 4.5 bar
- 2 Nipple
- 3 Instruction sheet

Q.ty

- 1
- 1
- 1

- ⚠ Bloccare i raccordi senza guarnizione tramite Loctite.

- ⚠ Block the fittings without gaskets with Loctite.

