

IT

SEPARATORE IDRAULICO ORIZZONTALE PER CALDAIA STAND ALONE

Questa istruzione è parte integrante del libretto dell'apparecchio sul quale viene installato l'accessorio.

A tale libretto si rimanda per le AVVERTENZE GENERALI e per le REGOLE FONDAMENTALI DI SICUREZZA.

⚠ Prima di effettuare qualsiasi operazione togliere l'alimentazione elettrica all'apparecchio.

⚠ Questo accessorio deve essere installato solo da personale professionalmente qualificato.

Il kit è composto da:

1	Separatore idraulico	Q.tà	1
2	Coibente separatore idraulico		1
3	Guarnizione 1" 1/2		5
4	Foglio istruzioni		1

EN

HORIZONTAL HYDRAULIC SEPARATOR FOR STAND ALONE BOILER

These instructions are an integral part of the installer manual on which the accessory is installed.


See the manual for the GENERAL WARNINGS, GENERAL SAFETY DEVICES.

⚠ Before carrying out any operation, first disconnect the electric power supply to the boiler.


⚠ The accessory must be installed by professional qualified personnel.

The kit is composed by:


1	Hydraulic separator	Q.ty	1
2	Insulating for hydraulic separator		1
3	1" 1/2 gasket		5
4	Instruction sheet		1



1



2



3

